


Instructions on how to use the converter/buck module


Photo of the 24V to 12V Converter/buck module



Step on how to install the converter/buck module:


1. **Input** : The input of the converter is red positive and black negative. They are connected to the 24V power offered by the truck. The input voltage can be 17V to 65V.
2. **Output**: The output of the converter is yellow positive and black

negative. They are connected to the control box of the cannon (see below). The output is 12V as the motor on the cannon is 12VDC.



To make it more clear, there is a video for your reference on how to convert from 24V to 12V. If you need, you could ask for it.

■ INSTALLATION WIRING



You could also find on how to install the converter from the manual of the cannon as above.