








Manual Rewind Hose Reel




Assembly Instructions







Required Tools







Parts List



3x	3/8-16 x 2½" Bolt 	14x	3/8" Flat Washer 	7x	3/8" Nut 
----	--	-----	---	----	---



4x	3/8-16 x 2" Bolt 	12x	5/16" Flat Washer 	2x	5/16" Nut 
----	---	-----	---	----	--



10x	5/16-18 x 7/8" Bolt 	8x	5/16" Lock Washer 
-----	--	----	--



4x	 <p>Thrust Washer</p>	2x	 <p>Retaining Ring</p>
----	--	----	--



1x	Swivel Assembly 	1x	Outer Swivel Plate 
----	--	----	---

1x	Bearing Assembly 	1x	Swivel Bearing Assembly 
----	---	----	--

1x	Hose Guide 	1x	Locking Hose Guide 
----	--	----	--


1x	Reel Axle Assembly 	1x	Hose Drum 
----	---	----	--

1x	Reel Crank 	1x	Reel Handle 
----	---	----	--


1x	Reel Frame 	1x	Reel Lock 
----	---	----	--

Step 1

Ensure proper orientation of the Hose Mount.




Bolt the Hose Guide without reel lock holes onto the Axle closest to the Hose Mount using four 5/16-18 x 7/8" bolts with four 5/16" locking and flat washers.



Step 2


Locking Hose Guide with reel lock holes must be opposite from the Hose Drum cutout.




Ensure the Hose Mount is 1/4" from the edge of the Hose Drum cutout.

Place Hose Drum over Axle.

Bolt the Locking Hose Guide with reel lock holes onto Axle using four 5/16-18 x 7/8" bolts with four 5/16" locking and flat washers.



Step 3




Step 4


Place Reel and both Bearing Assemblies onto Reel Frame.

Bolt each Assembly **loosly** to the Frame using four 3/8-16 x 2" Bolts, eight 3/8" washers and four 3/8" nuts.

The position of the reel will need to be adjusted before final assembly in step 6.




Step 5



Place two Thrust Washers over the Axle and into the Swivel Bearing Assembly. Install Retaining Ring, ensuring it is seated fully into the Axle groove. Place a third Thrust Washer after the Retaining Ring. Slide the Swivel Assembly over the Axle until it sits flush with the Swivel Bearing Assembly. Install the Outer Swivel Plate using three 3/8-16 x 2-1/2" bolts, six 3/8" washers and three 3/8" nuts.

Step 6



Install Reel Lock onto Frame using two 5/16-18 x 7/8" bolts, four 5/16" washers and two 5/16" nuts. Line up the Reel Lock pin with the Locking Hose Guide holes. Crank the reel a full turn to ensure it does not rub on the Hose Guide. Adjust if needed, then tighten bolts on the Reel Lock and Assemblies.

